


# HermanMiller Nelson™ X-Leg Table



## How to assemble your table.


For more information about our products and services or to see a list of dealers, please visit us at [hermanmiller.com](http://hermanmiller.com) or call (800) 851 1196.

© 2013 Herman Miller, Inc., Zeeland, Michigan Printed in U.S.A. Part No. 1bbgg9 - A.

©  is among the registered trademark of Herman Miller, Inc.


™ Nelson is among the trademark of Herman Miller, Inc.

### Tools Required




Power Driver


### Parts Included




(1) Top



(2) X-Leg (Qty: 2)



(3) Support Leg (Qty: 2)



(4) X-Leg Screw (Qty: 2)




(5) Philip Head Screw (Qty: 20)

### Step 1

**1.1**  
Position support leg to the straight in a way the screw holes on the X-leg are aligned to the screw holes on the support leg.

**1.2**  
Using power driver tighten the screw.


**1.3**  
Follow step 1 to install the another X-Leg and support leg.



### Step 2

**2.1**  
Rotate the top surface upward down and place it in a flat surface. Position X-leg to the top in a way the X-leg are aligned to the screw holes on the top.


**2.2**  
Using power driver tighten the screws.



### Step 3

#### 3.1

Repeat step 2 to assemble another leg.



### Step 4

#### 4.1

Rotate the table back to its original position.

