




Canvas Office Landscape® 3" Adapter & Change of Height Harness Installation and Disassembly for Recycling Instructions

3" Adapter:

Parts Included:



3" Adapter

WARNING


Disconnect power before installation. Failure to do so can cause electrical shock and personal injury.

WARNING

Electrically interconnected units must be mechanically interconnected.


Note: An Adapter is used with Festoon Connector to span from one frame to another when Frames are connected with Connector Tube.

Assembly Instructions: 1




1. Insert Adapter into Power Harness Port closest to installer. Make sure Clip on Harness fully engages onto Ramp on Adapter

2



1. Insert end of Festoon Connector into Adapter. Make sure clip on Adapter fully engages onto Festoon Connector.



3



1. Connect other end of Festoon Connector to Power Harness on adjacent Frame. Make sure clip on Power Harness fully engages onto Festoon Connector.


Change of Height Jumper Harness:

Parts Included:




A Change of Height Jumper Harness or **B** Festoon Jumper (FT154.1)

Assembly Instructions:



1. Connect Power Harness of different heights together with Jumper Harness (A). Make sure Clip on Power Harness fully engages onto Jumper Harness.



1. Connect Power Harnesses of different heights together with Festoon Jumper. Make sure Clip on Power Harness fully engages onto Festoon Jumper.

Disassembly for Recycling:

Materials Identification and Segregation:

Where possible, plastic components are marked with ASTM recycling codes. Use these codes to identify material type for recycling. Non marked components should be treated as mixed plastic. Ferrous metals can be identified using a small magnet for recycling. Non-ferrous metals should be separated and recycled separately.

To disassemble product, reverse the above installation steps.