



Canvas Office Landscape® Interiors Wall Start Installation and Disassembly for Recycling Instructions

⚠ WARNING

It is the responsibility of the installer to select and install the proper fasteners in a structural wall. Herman Miller does not furnish fasteners or assume liability for their use.

Parts Included:




A Plate



B Filler


Tools Required:




Power Driver




Drill Bit
(Determined by fastener)



Driver Bit
(Determined by fastener)



Level



Tape Measure



Safety Glass

Definition of a structural wall:

Herman Miller Inc. definition of a structural wall is a load-bearing wall constructed of materials such as poured concrete or concrete block or a composite board (dry wall) attached to metal or wood studs. Composite board (dry wall) must be 5/8" or more thick. Wood studs must be nominal 2" x 4" size. Metal studs must be "C" channel 20 ga. thick. Metal or wood studs must be on centers no greater than 24", have a maximum height of 14' and restrained at floor and ceiling.

Note: Refere to fastener manufacturer's specifications for pilot hole dia. size.

Installation guidelines:

- Fasteners for attaching into dry wall: #10 pan head machine screw with toggle bolt or hollow wall fastener. Screw length must be determined by wall construction and thickness.
- Fasteners for attaching into concrete: #10 pan head sheet metal screw and masonry anchor. Screw length must be determined by wall construction and thickness.
- Fasteners for attaching into studs through drywall: #10 pan head sheet metal screw. Screw length must be determined by wall construction and thickness.

IMPORTANT: Save these instructions for layout changes.

HermanMiller

Part no. 1b2jgc rev H.


© 2013 Herman Miller, Inc. Zeeland, Michigan. Printed in the U.S.A.

© **HermanMiller** and Canvas Office Landscape are among the registered trademarks of Herman Miller, Inc.


Illustrations and specifications are based on the latest product information available at the time of publication.

The right is reserved to make changes in design and specifications at any time, without notice, and also to discontinue products.


Assembly Instructions:




1. Adjust Glides to 4" from floor to bottom of frame.



2. Position Plate to structural wall 4" from Floor.
3. Level Plate vertically. If fastening into studs, proceed to step 3.
4. Mark anchor locations on structural wall through holes in Plate.
5. Remove Plate from Wall. Install Screw anchoring hardware, per manufacturers specifications, into wall.





3





6. Slide Plate (A) into Frame through Slot in bottom of Frame until end of plate is flush with bottom of Frame.

4



7. Secure Frame to wall with customer supplied Fasteners as perviously described in installation guidelines.

5



8. If Frame is to be installed in conjunction with Wall Strips, Wooden Filler must be installed on structural wall first.
9. Attach Filler to wall with customer supplied fasteners as described in installation Guidelines. Make sure Filler is vertically level and aligned with bottom of frame.
10. After Filler is installed, attach and center Frame to it as previously described in step 4.

Disassembly for Recycling:

Materials Identification and Segregation:

Where possible, plastic components are marked with ASTM recycling codes. Use these codes to identify material type for recycling. Non marked components should be treated as mixed plastic. Ferrous metals can be identified using a small magnet for recycling. Non-ferrous metals should be separated and recycled separately.

To disassemble product, reverse steps 10 through 1.