




Canvas Office Landscape® Electrical Harness and Harness Jumper Installation and Disassembly for Recycling Instructions

Parts Included:



A Power Harness

B Pan Head Self Tapping Screw (8)
Hardware Pack



C Harness Jumper


WARNING

Disconnect power before installation. Failure to do so can cause electrical shock and personal injury.


WARNING

Electrically interconnected units must be mechanically interconnected.

Tools Required:



#2 Phillips Bit
(6" Long)



Power Driver




Safety Glass

HermanMiller


Part no. 1b6pd1 rev B.

© 2013 Herman Miller, Inc. Zeeland, Michigan. Printed in the U.S.A.
® **HermanMiller**, Action Office, Intent, Canvas Office Landscape and are among the registered trademarks of Herman Miller, Inc.
™ Sense, Setu, and Be Collection are among the trademarks of Herman Miller, Inc.

Illustrations and specifications are based on the latest product information available at the time of publication.
The right is reserved to make changes in design and specifications at any time, without notice, and also to discontinue products.



1. Position Power Harness(A) onto Beam. Secure to Beam with Pan Head Tapping Screws(B) provided with Harness.



2. Connect Power Harnesses with Harness Jumper(C). Make sure Jumper Fully engages into Harnesses.

HermanMiller

Part no. 1b6pd1 rev B.

© 2013 Herman Miller, Inc. Zeeland, Michigan. Printed in the U.S.A.
 ®, HermanMiller, Action Office, Intent, Canvas Office Landscape and are among the registered trademarks of Herman Miller, Inc.
 ™ Sense, Setu, and Be Collection are among the trademarks of Herman Miller, Inc.

Illustrations and specifications are based on the latest product information available at the time of publication.
 The right is reserved to make changes in design and specifications at any time, without notice, and also to discontinue products.

Disassembly and Recycling:

Materials Identification and Segregation:

Where possible, plastic components are marked with ASTM recycling codes. Use these codes to identify material type for recycling. Non marked components should be treated as mixed plastic. Ferrous metals can be identified using a small magnet for recycling. Non-ferrous metals should be separated and recycled separately.

To disassemble product, reverse steps 2 through 1 and also do the following: