



Canvas Office Landscape® Beam-Trim Strip Installation and Disassembly for Recycling Instructions

Parts Included:




Tools Required:






- 1. Insert Square Nuts(C) into Grooves in Center Rail, 3 per side, evenly spaced. Align Nuts with holes in Rail.
- 2. Start Hex Socket Head Screws(B) into Nuts.

Part no. 1b6y35 rev B.



3. Insert and center Trim Strip(A) into Center Rail.



4. Tightening Hex Socket Head Screws(B) from both sides of Center Rail.

HermanMiller

Part no. 1b6y35 rev B.

Disassembly and Recycling:

Materials Identification and Segregation:

Where possible, plastic components are marked with ASTM recycling codes. Use these codes to identify material type for recycling. Non marked components should be treated as mixed plastic. Ferrous metals can be identified using a small magnet for recycling. Non-ferrous metals should be separated and recycled separately.

To disassemble product, reverse steps 4 through 1 and also do the following: