


# HermanMiller

## Canvas Channel Frame to Frame Connector Installation and Disassembly for Recycling Instructions



### How to assemble and reassemble your Frame To Frame Connector

#### Tools Required




Ratchet



9/16" Socket



9/16" Wrench



Torque Wrench




Safety Glass

#### Assembly Instructions

##### Step 1

1.1 Install Bolt, Washers at Top Hole location then Bottom Slot location of one of the Frames.2

1.2 Install Light Seal (D) over Bolts. Align Top Bolt with Top Slot in Light Seal.



#### Parts Included



Washer (4 or 6)



3/8-16 Hex Nut  
(2 or 3)



3/8-16 Hex Head  
Bolt (2 or 3)



Light Seal

#### Notice:

Make certain that fasteners are torqued to the specified values.


**IMPORTANT: Save these instructions for layout changes.**

##### Step 2

2.1 Align 2nd Frame with Bolts. Slide Frames together.

2.2 Install Compression Washers and Nuts. Hand tighten.

**Important: Torque Screws to 200 in-lbs. Start with Top Bolt, then Bottom and Middle last.**



## **Disassembly for Recycling:**

### **Materials Identification and Segregation:**

Where possible, plastic components are marked with ASTM recycling codes.

Use these codes to identify material type for recycling.

Non marked components should be treated as mixed plastic.

Ferrous metals can be identified using a small magnet for recycling.

Non-ferrous metals should be separated and recycled separately.

To disassemble product, reverse the above installation steps.