


HermanMiller

Mora™ System Wall Mounted Cases Installation and Disassembly for Recycling Instructions



How to assemble your Wall Mounted Cases

Tools Required





Step 1

1.1 Position Wall Cleat onto wall.

1.2 Measure distance (X) from Floor to bottom hole of wall cleat. Distance (X) will be 28 9/16" for standard 36" AFF worksurface or 26 9/16" for ADA 34" AFF worksurface. Mount the cleat at the highest point of the floor.


1.3 Measure 2" in from where case is to be located to find the vertical position of wall cleat. Mark Location.




Cleat orientation on wall

Parts Included

CH200.,CH210. Wall Mounted Cases



Additional Product Needed - Sold Separately





Note: Field supplied #10-3/16" Flat Washer.

Note: Please refer to Mora System planning guide for different wall constructions.

Step 2

2.1 Set up self-leveling laser to match mark, on wall.

2.2 Align Wall Cleat to level line and distance from outside cabinets. Using Cleat as template, mark mounting holes.





Step 3



3.1 Drill 1/2" hole at each marked location. Make sure there are no utilities present.

3.2 Insert Wall anchors and secure. Orient toggles vertically.

Note: Use all holes in cleat to mark and insert wall anchors and attachment screws in step 3.3.




3.3 Place cleat on wall. Insert screws with #10-3/16" flat washer supplied by customer.



3.4 For each run of product, toggle anchors should be installed into studs at each end. Where drawer units are installed, stud attachment is required. (Toggle attachment, not screws) It will be necessary to add holes in cleat for this attachment.


Note: If drawer units are installed as "stand alone", they must have 2 stud attachment points or have 14 gauge sheet metal backer in wall, attached to studs, to attach 2 anchors to.




Step 4

4.1 Arrange cases in proper location in run.

4.2 Mount Cases onto wall cleat.




4.3 Make sure cases mate tight together.



Step 5




WARNING! CH200 cases with drawers that are greater than 19” deep are at risk to dislodge from the wall and cause injury to a user and **MUST** be secured to the wall with two (2) wall anchors, two (2) 3.0” long machine screws, and two (2) washers (all included with case).

5.1 After step 4.3 is completed (may need to use clamps to assure the cases are tight together), remove all drawers, mark and drill two (2) 1/4” diameter holes through the back panel, cleat, and drywall in locations noted in image and table below.




Case Width (nominal)	"A" dim
18"	4"
24"	6"



5.2 After holes are drilled, unclamp cabinets (if needed) and disassemble from wall cleat. Install two (2) wall anchors in holes, as shown in step 3.1 & 3.2, and reassemble onto original location on the wall, making sure to line up the holes on the cabinet to the holes in the wall.



5.3 Secure cabinet to wall anchors using two (2) washers and two (2) 3” long machine screws, and reinstall drawers.




5.4 For all other cabinets, drill hole 5" down from top for 2" long pan head screw to attach case to wall cleat. This is for anti-dislodgement of unit.



Step 6


6.1 Drill 3 holes through mating side panels, 2 at front of cabinet (1 toward top and 1 toward bottom) and 1 at back in middle of cabinet. Holes should be inset 3" from front edge of side panel and 3" from back inside surface of back panel. Locate holes up or down as needed to avoid drawer slides or for appearance when installing printer cases.

6.2 Attach cabinets together with 3 Clamping Screws in ganging hardware pack CH110. When ganging open cabinet to drawer or door cabinet, make sure flat side of clamping screw is installed inside open cabinet for appearance reason.




Hinge Adjustment:

To adjust door up/down:




The bottom surface of the door should be flush with the bottom of the cabinet frame. To adjust door up, turn cam screw clockwise on right hinge. To adjust door down, turn cam screw clockwise on left hinge. Adjust both hinges on each door as necessary until proper door height is set.

To adjust door left/right:



To adjust door(s) left or right and or to tilt door(s) left or right, use lateral adjustment screw in hinge arm. Adjust screws in both upper and lower hinges to move SCREW doors left or right, or adjust screw in one hinge to tilt door left or right. Turning screw(s) clockwise moves door towards hinged side. Counter-clockwise to move door away from hinged side. Turn counter-clockwise for opposite door movement.

To adjust door in/out:



The front surface of a door should be flush with any adjacent doors and drawer fronts. Also the gap between the door and the sides of the cabinet should have a uniform gap. Turn screw clockwise to move door closer to side panels. Counter-clockwise to move door farther away from side panels.

Disassembly and Recycling:

Materials Identification and Segregation:

Where possible, plastic components are marked with ASTM recycling codes. Use these codes to identify material type for recycling. Non marked components should be treated as mixed plastic. Ferrous metals can be identified using a small magnet for recycling. Non-ferrous metals should be separated and recycled separately.

To disassemble product, reverse the above installation steps.